



Charging and activation

- Connect the watch charging cable to a 5 V / 1 A adapter and then connect the adapter to power. Align the cable with the metal contacts on the back of the watch. The built-in magnets will position the connector correctly.
- A new watch, or one that has not been used for a long time, may enter zero-voltage battery protection. Charge the watch for at least 15 minutes to activate it.
- When the device is not in use, charge it once a month, keep it fully charged and switch it off. This helps preserve battery life and proper operation.




Downloading the app

- Download the FitCloudPro app from the App Store or Google Play.
- You can also scan the QR code shown below.




First setup on iOS

- When opening FitCloudPro for the first time, allow access to Bluetooth, wireless data and notifications. If necessary, grant all required permissions in the phone settings.
- Choose to continue as a guest ("Visit As Guest") or sign in ("Sign In").






Connecting via Bluetooth - iOS

- In the app, select "Search Now" to find the watch and connect to its Bluetooth device.
- Accept the access request on the watch and complete pairing.
- On the phone, allow Bluetooth pairing and notifications.








Setting up FitCloudPro on Android

- Accept the FitCloudPro Privacy Policy and User Agreement, then sign in or choose to continue without an account.
- Enter your personal details. Allow the app to search for nearby devices and use Bluetooth.






Pairing and permissions - Android

- Allow FitCloudPro to discover and connect to devices.
- Tap the watch name, accept the request on the watch and complete pairing.
- Allow Bluetooth pairing and access to contacts if you want to synchronize contacts.





Enabling notifications

- The watch cannot receive notifications when the phone is in Do Not Disturb mode.
- Make sure Bluetooth is enabled, the FitCloudPro app is running and the watch is connected to the phone.
- Make sure notifications from the relevant app are visible in the phone's notification bar, then enable them in FitCloudPro.




Weather and units

- In FitCloudPro, enable weather reports and location access to receive weather forecasts.
- In the device settings in the app, choose the units you use, such as Celsius or Fahrenheit and metric or imperial units.




Setting and downloading watch faces

- Press and hold the watch face for about 2 seconds, then swipe to change the watch face.
- Download additional watch faces from the watch-face gallery in FitCloudPro.
- Only one downloaded watch face can be stored on the watch at a time. Downloading a new one replaces the previous watch face.



Using the touchscreen

- Swipe from the main watch face to move between the control center, menu, phone keypad and messages.
- The swipe directions and corresponding screens are shown in the illustration.



Resetting the watch and call audio

- To reset the watch, select: Settings > System > Reset.
- If activity, sleep or heart-rate data is inaccurate, or Bluetooth or calling does not work, reset the watch and pair it again.
- You can also reset or update the firmware from the app.
- Tap the phone icon to enable or disable Bluetooth calling.




Settings



System



Reset




Media audio and connection status

- To stop the watch from playing media audio or making and answering calls, disable Media audio and Call audio.
- The watch can display the app connection status and Bluetooth calling status separately.
- On iOS, message reminders may work after the app is closed. On Android, FitCloudPro must remain running in the background.



BT Call and APP
Disconnected





APP Connected
BT Call Disconnected



APP Connected
BT Call Connected

Adding and synchronizing favorite contacts

- Add contacts to the watch using the FitCloudPro app.
- For privacy reasons, some phones require Bluetooth contact synchronization to be enabled manually in the system settings.



Important safety information

- Do not expose the watch to very high temperatures, intense sunlight or heating appliances such as heaters, ovens, microwave ovens or water heaters. High temperatures may damage the battery or cause it to explode.
- The product contains a non-removable cobalt battery. People without the appropriate qualifications must not disassemble the device.
- The watch has passed water-resistance tests, but wear and usage may reduce its sealing performance. Use it carefully when swimming or diving. Do not use it in a sauna or while taking a hot shower.
- This product is not a medical device. Heart rate, blood oxygen, sleep, calories, steps and other health data are for reference only and must not be used as the basis for a clinical diagnosis.